

SOLID GOLD

The perfect setting for diamonds

SIZE	MM DIAMETER
A	11.95
A 1/2	12.18
B	12.37
B 1/2	12.60
C	12.78
C 1/2	13.00
D	13.21
D 1/2	13.41
E	13.61
E 1/2	13.83
F	14.05
F 1/2	14.15
G	14.36
G 1/2	14.56
H	14.65
H 1/2	14.86
I	15.04
I 1/2	15.27
J	15.40
J 1/2	15.70
K	15.80
K 1/2	16.00
L	16.10
L 1/2	16.41
M	16.51
M 1/2	16.71
N	16.92
N 1/2	17.13
O	17.35
O 1/2	17.45
P	17.75
P 1/2	17.97
Q	18.19
Q 1/2	18.35
R	18.61
R 1/2	18.80
S	19.10
S 1/2	19.31
T	19.51
T 1/2	19.84
U	20.02
U 1/2	20.20
V	20.32
V 1/2	20.68
W	20.76
W 1/2	20.94
X	21.18
X 1/2	21.30
Y	21.49
Y 1/2	21.69
Z	21.89
Z 1/2	22.10

To establish your ring size:


a) Take the INTERNAL diameter measurement of one of your existing rings and equate it to the chart on the left.

Or

b) Use the ring size ruler on the right.

To use the ruler:

- 1) Print this PDF at 100% - make sure that the 'Page Scaling' is set to 'None' in the 'Print Handling' section of the print screen.
- 2) Measure the line below, it should measure 5cm. If this is the case, then you have printed this page out to the correct size.



- 3) Place your ring on the bottom of the scale on the right with its inside left edge on the left edge of the circle.
- 5) Slide the ring up the scale, looking through the centre until you can see the right hand line.
- 6) The ring size you need is shown inside the ring.



This indicates a ring with a size of P 1/2

